

Moving to Digital

*Initial Experiences
Developing Camera-Based
Neutron Imaging Capabilities*

Aaron E. Craft
Idaho National Laboratory

AUNIRA
*Presented at TUM, FRM-II
August 30, 2017*

www.inl.gov




BRIEF Background

What we do at INL

How we currently do NR



Why it is important

First experiments with a camera-based system



Idaho National Laboratory - Overview


- Est. 1949 as the National Reactor Testing Station and Argonne-West
- Location of the first nuclear power plant in 1951
- Developed Navy nuclear propulsion systems
- First demonstration of the breeder reactor concept
- Designed, constructed and operated 52 nuclear reactors
- The United States' leading nuclear **energy** laboratory




Idaho National Laboratory - Overview

- 2250 km² (~40× Manhattan, ~90% Luxembourg, 20× Paris, 37000× Louvre)
- 180 km of electrical transmission and distribution lines
- ~580 buildings
- 285 km of paved roads
- 300 metric tons of used fuel
- ~4000 employees
- 4 reactors


Materials and Fuels Complex



Research and Education Campus




Reactor Technology Complex




Current Neutron Radiography Capabilities

DYSPROSIUM







INDIUM





Neutron Tomography from Film Radiographs



- Requires expensive and time-consuming acquisition of a full set of radiographs
 - Costly, but provides extremely valuable data



Jennsen et al., 2013, Prog. Nuc. En.




L07 Test, INL/EXT-13-30741-01




Abir, et al, Journal of Rad. & Nuc. Chem. (2016)

Development of Computed Tomography

- Computed tomography was performed to determine coolant channel gap widths of the AFIP-7 element
- Limited angle tomograph:
 - 42 projections at 1.25° increments,
 - Total of 252 radiographs (*very costly and time-consuming*)
- Illustrates the need for digital systems before CT can be used routinely
- Performing neutron computed tomography without a digital neutron imaging system is like “*having your cart before your horse,*” it may work but it’s not recommended



Radiographs of AFIP-7 fuel assembly at three different angles.



3D reconstruction of a 36 cm axial segment of 4 fuel plates inside aluminum cladding.




Neutron Imaging Goals

Make neutron tomography a *routine* PIE capability

<u>Need for CT</u>	➔	<u>TODAY</u>	➔	<u>FUTURE</u>
rotation stage		single-use stage		universal stage
image acquisition		transfer technique		digital
image registration		semi-automatic		automatic
CT reconstruction		subcontract & postdoc		semi-automated
<i>“Will it work for my experiment?”</i>		<i>“Not sure. Maybe?”</i>		<i>“We can find out.”</i>

Radiography of Radioactive Specimens



- Some neutron radiography systems are not gamma sensitive

Direct method


Indirect (transfer) method

Scintillation screens and CCD camera

Multi-Channel Plate (MCP) detectors

← Been doing for ~45 years

Radiography of Radioactive Specimens



- Some neutron radiography systems are not gamma sensitive
 - ❌ Direct method
 - ✅ Indirect (transfer) method
 - ❓ Scintillation screens and CCD camera ← Exploring other options
 - ❓ Multi-Channel Plate (MCP) detectors

Developing a Scintillator-CCD System

- Digital capabilities in the North Radiography Station (NRS) will enable evaluation of non-rad objects developed at INL.
 - Fuel cells, batteries, homeland security, petroleum industry, material fabrication processes, hydridization of zircaloy, etc.
 - Could provide digital neutron imaging of dynamic processes.
- Purchased a system with a 10 cm × 10 cm FOV and a nice camera.
- Other activities showed high radiation background in the NRS, so we wanted to test a less-expensive system first to get some experience.



Andor iXon Ultra 888; Andor Technology Ltd.



ZWO 178 MM Cool



When Trying Something New, Talk to an Expert



Collaborations at INL

- Invited Burkhard Schillinger to visit INL.
- Prior to his arrival:
 - Ordered various equipment prior to activities.
 - Cameras, lenses and adapters, scintillator screens, cables, shielding materials, light-tight enclosure materials, stepper motors, et al.
 - We did not want to be limited by materials.
 - Built and prepared a few things ahead of time.
 - Avoid wasting time. Plan ahead as best possible.
 - Selected some important system variables.
 - Desired field of view (FOV).
 - Location of installation.
 - Prepare colleagues and required resources.
- Then it's time to get to work. (*i.e. Burkhard arrives*)

You have only three working days to build your system. Get started!

Overview of Tasks

- Day 1:
 - Evaluate available materials. (Get any additional materials you need)
 - Take measurements with various camera and lens combinations.
 - Build and test a control system for integrating the motors and camera.
 - Choose a system configuration that works.
- Day 2:
 - Assemble the system and prepare for installation in the beam.
 - Troubleshooting.
- Day 3:
 - Install and test the system.
 - Troubleshooting.
- Success: Produce a digital neutron radiograph with a camera-based system for the first time.

Test Combinations of Cameras and Lenses

- Measured distance from the CCD chip (*not the lens*) to image plane for each combination.
 - Provides a coarse focus; fine tuning comes later.
 - This knowledge saves time later when designing a system or making adjustments.
- A lens has a range of object-detector distances (ODD) in which it can focus.
 - If the distance is less than this, the lens must move away from the CCD to focus.
 - Spacers (i.e. shims) can be placed between the camera and lens to provide the needed separation distance.


- Chosen system:

- ZWO 178 MM Cool (~\$700)
3096x2080 pixels,
2.4 μm pixels, 14-bit ADC
- 25 mm lens
- ODD ~762 mm
- 1.0 mm spacer between camera and lens

Camera	Lens	Focus Distance (mm)
ATIK 414 EX	35 mm	825
	25 mm	626
	16 mm	375
ZWO 174 MM Cool	50 mm	940
	35 mm	692
	25 mm	495
ZWO 178 MM Cool	25 mm	762
	16 mm	445



↑
up






→ right

Overview of Tasks

- Day 1:
 - Evaluate available materials. (Get any additional materials you need)
 - Take some basic measurements with cameras and lenses.
 - Build and test a control system for integrating the motors and camera.
 - Need a way to simultaneously control the rotation stage and image acquisition.
 - Choose a system configuration that works.
- Day 2:
 - Assemble the system and prepare for installation in the beam.
 - Troubleshooting.
- Day 3:
 - Install and test the system.
 - Troubleshooting.
 - Produce a digital neutron radiograph with a camera-based system for the first time.

“How to set up the Raspberry Pi and Gertbot as a tomography controller”

Document available on ISNR website






DELL

on Ca
LA & vegetable

THOR PDS

CM 15°C 24AWG ETC

```
pastatagep 790  
kuglem 22.48309227452424  
pastatagep 822  
kuglem 23.24098009239764  
pastatagep 898  
kuglem 24.22940149825958  
pastatagep 888  
kuglem 23.1871570703190  
pastatagep 921  
kuglem 24.394912718204498  
pastatagep 854  
kuglem 24.85288122817208  
pastatagep 997  
kuglem 27.820423340149623  
pastatagep 1000  
kuglem 28.728179981122198  
pastatagep 1088  
kuglem 28.82283182284748  
pastatagep 1088  
kuglem 30.52363773047830  
pastatagep 1118  
kuglem 31.821444540338  
pastatagep 1152
```




DELL

A Few System Design Parameters

- Camera centered at the center of the beam, 53 cm above the floor
- Reactor at 250 kW, $L/D_{\text{eff}}=270$, $\phi \approx 2.0 \times 10^6 \text{ n/cm}^2\text{s}$
- Used an inexpensive *ZWO 178MM Cool with Sharp Cap 2.9* free software
- Radiation shielding for the camera and electronics
 - Lead bricks around the camera, at least 5 cm thick, preferably more
 - Borated poly (B_4C /silicone and B_4C /polyethylene)
 - Lithiated polyethylene purchased but not used because of fast neutron generation.
 - A particle transport model would be very beneficial for designing shielding

Testing Connections and Focusing Camera




Shielding the power supply for the rotation motor



Stacking the shielding






**Shielding
Materials**


Object

**Converter
Screen**

First Light




First Light



Celebrating Success

Got the system up and running with help from a colleague and learned many lessons



Digital improvements


INL researchers and a visiting German colleague produced the first digital neutron radiographs using a modern camera-based neutron imaging system at NRAD.

Running Solo Shortly After the Visit

- A second test using this system examined a surrogate prismatic fuel element with engineered flaws inside coolant channels.
- The sample rotation stage was mounted to a linear stage so it could be remotely positioned so a light image could be acquired.
- Widened the gap for somewhat improved ventilation.








```
pi@raspberrypi:~/gertbot
print('')
print('tomography complete!')
print('')

# on exit stop everything
gb.emergency_stop()

pi@raspberrypi:~/gertbot $
pi@raspberrypi:~/gertbot $ python3 INLtomo.py

Now move your mouse from the SSH shell window to the camera window
click into the window once to activate it,
and move the mouse pointer on the start button for you
This script will begin execution in five seconds.


angle= 0.0
aststeps= 0
angle= 0.8977556109725686
aststeps= 32
angle= 1.7955112219451372
aststeps= 65
angle= 2.693266832917706
aststeps= 98
angle= 3.5910224438902745
aststeps= 131
angle= 4.488778054862843
aststeps= 164
angle= 5.386533665835412
aststeps= 197
angle= 6.28428927680798
aststeps= 230
angle= 7.182044887780549
aststeps= 263
angle= 8.079800498753118
aststeps= 296
```

SharpCap - ZWO ASI178MM-Cool (via USB2) - C:\Users\raspi\Desktop\SharpCap Captures\2017-05-11\Capture\08_52_12 - C:\Users\raspi\Desktop\SharpCap Captures

File Cameras Options Capture Tools Scripting Help

Start Capture Quick Capture Stop Capture Pause Snapshot Live Stack Object Name: - FX: None - Zoom: Auto


Quick Capture started for 20 seconds. Use the Quick Capture drop down to choose from different quick capture options.



Camera Control Panel

- Capture Profiles: 20s_5-1-2017 (ZWO ASI178MM-Cool)
- Capture Format and Area: Colour Space: MONO16, Capture Area: 3096x2080, Binning: 1
- Camera Controls: Exposure: 20.0 s, LX Mode:
- Image Controls: Gamma: 100, Brightness: 1, Timestamp: Off
- Thermal Controls: Cooler: On, Target Temperature: -15, Cooler Power: 100, Temperature: -14

Histogram





Capturing: 0 frames (0 dropped) in 0:00:04, current exposure 20.0s, last frame 20.4s (Cooler at 100%, Temp: -14.1C, Target: -15.0C) Frame: 00:26 / 00:06 Time left: 00:26 (ETA 8:52 AM)

Windows Explorer window showing file system:

- Videos
- 08_51_48
- 08_52_12
- Computer
- OSDisk (C:)
- Network


3D Items

Orthogonal Views





Running Solo Shortly After the Visit


- The system was able to acquire 32 neutron radiographs in under 12 minutes.
 - Current production is limited to ~14 film radiographs per day.
- Radiographs acquired with specimen rotated at 10° increments.
 - An upset in the USB hub stopped acquisition after 32 radiographs.
- No single radiograph clearly shows the feature, but it becomes clear as the object rotates. Tomography should provide additional and higher-quality information.



Close-up view of the object positioned in front of the scintillator screen.



Orthogonal neutron radiographs of the surrogate prismatic fuel element.



Example radiograph at 45° ([link to video](#))

Challenges

- Access to the beamline hutch should be made as simple a procedure as possible. Multiple entries are inevitable.
 - Iris needs adjusted or lens refocused.
- Very high background radiation causes upsets in electronics.
 - *Very high gamma and epithermal neutron content.*
 - Need to improve the shielding approach for camera.
 - Perhaps modification of the neutron beamline.
 - Move all nonessential electronics outside the bunker.
- Cooling the camera.
 - Initially -15°C , but could only get to -10°C after an hour due to heat building up in the lead shielding.
 - Need more ventilation through camera shielding or water cooling.
- This valuable experience helped us to be able to operate the system on our own.

Upcoming Activities

- Building two new systems with FOV's of 20 cm and 10 cm square.
- A double-mirror system should reduce scattered radiation to the camera.
- Camera mounted to a linear stepper motor for remote focusing.
- Radiation transport models under development to assess shielding options.



Supplemental Slides:
More About NRAD




Idaho National Laboratory




Hot Fuel Examination Facility (HFEF)

- One of the world's largest inert atmosphere hot cells
- Primarily used for post-irradiation examination (PIE) of irradiated nuclear fuel experiments






27 m × 9 m



NRAD Reactor


- Designed specifically for neutron radiography for PIE of fuel
- The NRAD reactor beneath the HFEF hot cell
 - 250 kW TRIGA
 - Two neutron beams
- Access to specimens in the hot cell
- *A unique and valuable facility*




NRAD Reactor




NRAD Reactor Core






East Radiography Station (ERS)

- The ERS sits directly beneath the main hot cell
- A foil cassette is remotely moved behind the elevator




East Radiography Station (ERS)

- Elevator positions specimens into the ERS cell




East Radiography Station (ERS)

- Category-I radiography facility according to ASTM standards
- Image area: 17.8 cm × 43.2 cm (7" × 17")
- Neutron flux: $\sim 9.5 \times 10^6$ n/cm²-s
- L/D ratio: 50, 125, 300 (L = 4.45 m)




North Radiography Station (NRS)




North Radiography Station (NRS)

- NRS is not beneath the hot cell
- Equipment and specimens can be placed in the NRS cell by hand
- Easier access to NRS
- FOV up to 50 cm
- L/D ratio: 185, 300, 700
- Neutron flux: $\sim 4.5 \times 10^6 \text{ n/cm}^2\text{-s}$
- NRS is ideal for:
 - Detector development
 - Unirradiated objects
- Recovery of NRS is underway
 - Was used for other experiments




Radiography at the NRAD

- Transfer method radiography is currently employed at the NRAD
 - Neutron beam passes through the specimen and activates the foils in the cassette




Radiography at the NRAD, cont.

- Transfer method radiography is currently employed at the NRAD
 - Neutron beam passes through the specimen and activates the foils in the cassette



Radiography at the NRAD, cont.


- Transfer method radiography is currently employed at the NRAD
 2. Foils are removed from the cell and taken to a nearby dark room
 3. X-ray film placed into contact with the activated foils
 4. Decay radiation from foils exposes the film (over night)
 5. Film is developed and scanned



- This is *typically* the only radiography technique used for nuclear fuel
 - For highly radioactive objects, transfer method radiography is still the state of the art

Neutron Computed Radiography

- Developing a new capability that uses image plates (IP) for neutron computed radiography (*n*CR)
- Same transfer method as film



- Removes film development and scanning (↓ time, ↓ cost)
- IPs are reusable, but consumable